



Temperature Sensing Above 1000°C Using Cr-Doped GdAlO₃ Spin-Allowed Broadband Luminescence

Jeffrey I. Eldridge
NASA Glenn Research Center
Cleveland, OH
USA

Matthew D. Chambers
Raytheon Vision Systems
Goleta, CA
USA

9th International Temperature Symposium
Anaheim, CA
March 20, 2012

Background

- Thermographic phosphor temperature measurements use luminescence from transition metal or rare earth dopants.

Transition metal (e.g., Cr ³⁺) 3d transitions	Rare earth (e.g., Dy ³⁺) 4f transitions
Unshielded	Shielding by 5s & 5p electrons
Strongly phonon & bonding coupled	Weakly phonon & bonding coupled
Very strong spin-allowed absorption oscillator strength✓	Very weak spin-forbidden oscillator strength (by ~4 orders of magnitude)
Strong thermal quenching Cr:Al ₂ O ₃ performs to 600°C	Weak thermal quenching✓ Dy:YAG performs up to 1700°C
Short λ emission not available (R lines @~700 nm)	Short λ emission available✓ (Dy ³⁺ @456 nm)

- No high luminescence intensity phosphors for T>1000°C where high intensity is needed in presence of strong thermal radiation background.


Objective

- Obtain best-of-both-worlds performance of high intensity emission that persists above 1000°C.


Approach

- Select Cr-doped phosphor with strong crystal field at dopant site to delay thermal quenching of luminescence.
 - Cr-doped GdAlO₃ (Cr:GAP)
- Utilize shorter-wavelength spin-allowed broadband emission for reduced interference from thermal radiation background.
- Demonstrate extended high temperature performance above 1000°C.
- Demonstrate optical thermometer using luminescence decay of Cr:GAP.

Basis for Phosphor Matrix Selection










Tanabe-Sugano Diagram









Matrix Candidate: RAlO₃ Perovskite

Tightly bonded AlO₆ Octahedra Exhibit Strong Crystal Field







Summary



- Spin-allowed broadband luminescence from Cr:GAP exhibits exceptional persistence to high temperature for thermographic phosphor temperature measurements up to 1200°C.
 - Strong crystal field.
 - Spin-allowed broadband emission from 4T_2 level "stabilized" by underlying long-lived 2E reservoir level.
 - Growth of spin-allowed broadband emission shifts emission to more useful shorter wavelengths (730→570 nm).
- Optical thermometer based on Cr:GAP decay at tip of sapphire lightguide demonstrated to 1075°C.
 - Sapphire fluorescence limits usefulness to $T < 1100^\circ\text{C}$.

Acknowledgments

- Funding by the NASA Fundamental Aeronautics Mission Directorate Seedling Fund.